

- Перед использованием изделия необходимо внимательно прочесть настоящую инструкцию и предупреждения с целью обеспечения безопасности.
- Настоящую инструкцию следует предоставить сотруднику, который будет фактически отвечать за эксплуатацию и техническое обслуживание изделия.

ТЕХНИКА БЕЗОПАСНОСТИ

- Перед тем как приступить к монтажу, подключению, эксплуатации, техническому обслуживанию и осмотру устройства, необходимо внимательно ознакомиться с инструкциями по технике безопасности и следовать их указаниям для надлежащего выполнения работ.

ОПАСНОСТЬ: Нарушение требований и правил, указанных после данного обозначения, может привести к смерти или серьезным травмам.

ПРЕДУПРЕЖДЕНИЕ: Нарушение требований и правил, указанных после данного обозначения, может привести к легким травмам или физическому ущербу.

ОПАСНОСТЬ

- Выключать находящийся выше по схеме автоматический выключатель перед установкой или сервисным обслуживанием изделия, чтобы исключить возможность поражения электрическим током и ожога в случае короткого замыкания.
- Не прикасаться к оголенным проводам, находящимся под напряжением, т.к. это может привести к поражению электрическим током.

SAFETY PRECAUTIONS

- Before installation, wiring, operation, maintenance and inspection of the device, be sure to read the safety precautions carefully and follow the message to ensure proper operations.

DANGER : Offending against the message will result in death or serious injury.

CAUTION: Offending against the message will result in minor injury or physical damage.

DANGER


- Turn off the upstream circuit breaker before installation or service to prevent electric shocks and burns due to short circuit,
- Do not touch any live naked terminals,
It makes an electric shock.

CAUTION

- Before installation, be sure to read the manual carefully to ensure proper operation.
- Installation, maintenance and inspection of the circuit breaker should be performed by qualified engineers having special knowledge.
- Do not install the circuit breaker in place of environment with shock, high temperature, humidity, dust, corrosive gases, excessive vibration, etc, to prevent fire accidents and malfunction of the device,
 - Humidity : 45~85%
 - Altitude : less than 2000m
- Use the breaker in a range of the rated voltage and current shown on the name plate,
Or it may cause malfunction.
- Please tighten the terminal screw in proper torque to prevent overheating,
- Each crimp terminal or conductor pole should be connected parallel.
- When mounting more than one breaker side by side, fit interphase barriers between terminals, If the breaker has no interphase barrier, insulate the exposed part of the terminals or conductors with insulation sleeves or tape or attach terminal covers, (sold separately)
- Be sure to fit interphase barriers between terminals,
- When the circuit breaker trips of itself, remove the cause and turn the handle on,
Or it may lead to the fire accident.
- Be careful not to be damaged by accidents during transportation or installation,
- When the device become useless, it should be dispose of them as an industrial waste,
- Do not connect aluminum terminals and conductors to the breaker directly,
Or it may cause corrosion and overheating.
- Do not modify the device unless it is permitted.


TS400

TS630




Автоматический выключатель
Circuit breaker


2P : 2 шт.	2P : 2ea
3P : 4 шт.	3P : 4ea
4P : 6 шт.	4P : 6ea
4P R : 6 шт.	4P R : 6ea
2P : 4 шт. (M10x30)	2P : 4 ea (M10x30)
3P : 6 шт. (M10x30)	3P : 6 ea (M10x30)
4P : 8 шт. (M10x30)	4P : 8 ea (M10x30)
4P R : 8 шт. (M10x30)	4P R : 8 ea (M10x30)




1




2,3P




4P




4P R




M5x85




2




3



4



5



Расцепитель (Trip unit)

ATU, FMU, FTU : теплозлектромагнитный
ETS, ETM : электронный
MTU : только с электромагнитным расцепителем
DSU : выключатель-разъединитель

ATU, FMU, FTU : Thermal-magnetic
ETS, ETM : Electronic
MTU : Magnetic only
DSU : Disconnecting switch

ATU
0.9
0.8
I_r (xIn)
6 7 8
5 10
II (xIn)
630A
40°C
3P

FMU
0.9
0.8
I_r (xIn)
630A
40°C
3P


FTU
0.9
0.8
I_r (xIn)
630A
40°C
3P

ETS
TEST
ATU
0.9
0.8
I_r (xIn)
8
7
6
5
10
II (xIn)
630A
40°C
3P


ETM
TEST
0.9
0.8
I_r (xIn)
11
10
9
8
7
6
5
4
3
2
1
II (xIn)
630A
40°C
3P

MTU
TEST
0.9
0.8
I_r (xIn)
4200 4500
3600 5400
3000 6000
500A


DSU
DSU
630A
3P



6



7




ВКЛ.
ON



Нажать для отключения
Push to trip

ОТКЛЮЧЕН
TRIPPED



ВЫКЛ.
OFF

LS'**IS**

Технические вопросы и постпродажное обслуживание —
Центр поддержки клиентов — быстрый ответ на вопросы, отличная техническая поддержка
Тел.: 82-1644-5481 | Домашняя страница: <http://www.lsisis.com>

Приведенные в настоящем руководстве технические характеристики могут
быть изменены в результате технической доработки и модернизации изделия.

LS'**IS**

Technical Question or After-sales Service
Customer Center — Quick Responsive Service, Excellent technical support
TEL. 82-1644-5481 | Home page. <http://www.lsisis.com>

Specifications in this instruction manual are subject to change without notice
due to continuous products development and improvement.